

		All-In-One Kits					
Model	Year	All-In-One Analog	All-In-One Wireless			Repl. Air Spring	
Chevrolet/GMC Pickup Trucks							
Silverado, Sierra 2500HD, 3500HD (2WD, 4WD)	11-16	2801	2806	*	2.5	6401	
Silverado, Sierra 2500HD, 3500HD (2WD, 4WD)	01-10	2809	2808	*	2.5	6781	
Ford Pickup Trucks							
F250, 350 (2WD, 4WD) Diesel	11-16	2803	2802	*	2.5	6401	
F250, 350 (2WD, 4WD) Gasoline (not V10 gas w/extended cab and 8' bed)	11-16	2801	2800	*	2.5	6401	
F250, 350 (2WD, 4WD)	08-10	2801	2800	*	2.5	6401	
F250 Over 8,500 GVWR (2WD, 4WD)	99-04	2801	2800	*	2.5	6401	
F350 (2WD, 4WD) (not V10 gas w/extended cab and 8' bed)	99-04	2801	2800	*	2.5	6401	
Ram Pickup Trucks							
Ram 1500 Mega Cab (2WD, 4WD)	06-08	2805	2804	*	2.5	6401	
Ram 2500 (2WD, 4WD)	13	2805	2804	*	2.5	6401	
Ram 2500 (2WD, 4WD)	03-12	2805	2804	*	2.5	6401	
Ram 3500 (2WD only)	07-12	2805	2804	*	2.5	6401	
Ram 3500 (2WD only)	03-06	2805	2804	*	2.5	6401	
Ram 3500 (4WD only)	03-12	2805	2804	*	2.5	6401	
Toyota Pickup Trucks							
Tundra (2WD, 4WD), TRD	07-16	2811	2810	*	2.5	6410	

*No-Drill applies to the Air Spring component installation. To accomplish No-Drill for entire installation, purchase the Air Accessory Mounting Kit. See page 52.

The complete kit so you can Ride Rite

All-in-One Kits come with Air Springs, compressor, air accessories and all components for install. Choose between Wireless or Analog.

- Combines Air Spring Kit and Air Accessory Kit
- 1 part number for easy ordering
- Discounted overall price
- Recommended: No-Drill Air Accessory Mounting Kit (see page 52)



DO NOT EXCEED THE VEHICLE'S RECOMMENDED GROSS VEHICLE WEIGHT RATING (GVWR)