

Firestone's Air Accessory Mounting Kits allow the compressor only, tank only or entire air accessory system to be pre-assembled table top, before the vehicle is on the lift. The plate with the assembled accessory system can easily be attached to the frame, without drilling using bail clamps.



2518 Kit Installed on Dodge 1500 which includes the 2496 and 2529 Air Accessory Mounting Kits.



Air Accessory Mounting Kit 2497 shown with 9287 compressor.



Air Accessory Mounting Kit 2529 shown with Kit 2541 preassembled.

For Air Tanks

2496 - Brackets clamp to vehicle with u-bolts. Will fit all Firestone tanks except 9166. Will also work with the following kit: 2546*



For Air Command Kits

2529 - Compressor, ECU and valve block mount to plate without drilling. Plate clamps to vehicle with u-bolts. Will work with the following kits:

- 2489
- 2490
- 2491
- 2540
- 2541
- 2544
- 2545
- 2546*
- 2547*
- 2554
- 2555
- 2556



For Compressors

2497 - Will work with the following kits:

- 2097
- 2158
- 2178
- 2219
- 2538
- 9284
- 9285
- 9287
- 9377



For Air Tank and Compressor

2530 - Will work with the following kits:

- 2047
- 2168
- 2198
- 2232
- 2239
- 2266
- 2543
- 2547*
- 2549



*This kit requires two mounting plates. For **2546 Xtra Remote Air Command**, use the 2529 and 2496. For **2547 Xtreme Remote Air Command**, use the 2529 and 2530.