




Control Panels

Metal Control Panels



Pneumatic		Replacement Gauge
White	2225	9181
Black	2149	9084
Electric		Replacement Gauge
White	2229	9181
Black	2191	9084


Pneumatic		Replacement Gauge
White	2241	9201
Black	2145	9073
Electric		Replacement Gauge
White	2260	9201
Black	2188	9073

Pneumatic	
Black	2333

Monitoring Gauge	
White	2196

Replacement Switch	
Pneumatic	9074 - With Air Tank
Electric	9039 - No Air Tank

Plastic Control Panels



Pneumatic		Replacement Gauge
White	2570	9181
Black	2571	9084
Electric		Replacement Gauge
White	2572	9181
Black	2573	9084

Pneumatic		Replacement Gauge
White	2574	9201
Black	2575	9073
Electric		Replacement Gauge
White	2576	9201
Black	2577	9073

How do I know if I need a pneumatic or an electric control panel?

- Pneumatic control panels are used in systems that utilize tanks.
- Electric control panels do NOT require a tank.

What is the difference between single and dual control panels?

- Single control panels inflate and deflate one pair of air springs.
- Dual control panels inflate and deflate two individual air springs or two pairs.

