

Level Command System™

Level Command Systems are comprised of an air supply kit and a height sensor kit to automate the inflation of your air springs, keeping them at a controlled height.

Air Supply Kits

Air Supply Kits offer an on-board air source for inflating air springs, tires, rafts and other pneumatic components. Kits include a compressor, an air tank and a 25 ft. extension hose.

Kit Part #	2047 (Xtra)	2239 (Xtra 3 Gallon)	2548 (Xtreme)
COMPRESSOR	 9285	 9285	 9287
AIR TANK	 9124	 9127	 9420
HOSE	 9006	 2311	 2311